

# *SPIRIT*



## **XE195** Elliptical Trainer

### OWNER'S MANUAL

Please carefully read this entire manual before operating your new elliptical.

# Table Of Contents

Important Safety Instructions.....3

Important Electrical Instructions.....4

Important Operation Instructions.....5

Assembly Instructions.....6

Operation of Your Console.....12

Programmable Features.....16

Using A Heart Rate Transmitter.....20

Using the Spirit FIT App.....21

General Maintenance.....22

Exploded View Diagram.....23

Parts List.....24

**ATTENTION**

This elliptical is intended for residential use only and is warranted for this application. Any other application voids this warranty in its entirety.

# Important Safety Instructions

**WARNING** - Read all instructions before using this appliance.

**DANGER** - To reduce the risk of electric shock disconnect your elliptical from the electrical outlet prior to cleaning and/or service work.

**WARNING** - To reduce the risk of burns, fire, electric shock, or injury to persons, install the elliptical on a flat level surface with access to a 230-volt, 10-amp / 120-volt, 15-amp grounded outlet with only the elliptical plugged into the circuit.

**DO NOT USE AN EXTENSION CORD UNLESS IT IS A 18AWG OR BETTER, WITH ONLY ONE OUTLET ON THE END:**

1. Do not operate elliptical on deeply padded, plush or shag carpet. Damage to both carpet and elliptical may result.
2. Keep children away from the elliptical. There are obvious pinch points and other caution areas that can cause harm.
3. Keep hands away from all moving parts.
4. Never operate the elliptical if it has a damaged cord or plug. If the elliptical is not working properly, call your dealer.
5. Keep the cord away from heated surfaces.
6. Do not operate where aerosol spray products are being used or where oxygen is being administered. Sparks from the motor may ignite a highly gaseous environment.
7. Never drop or insert any object into any openings.
8. Do not use outdoors.
9. To disconnect, turn all controls to the off position, then remove the plug from the outlet.
10. Do not attempt to use your elliptical for any purpose other than for the purpose it is intended.
11. The hand pulse sensors are not medical devices. Their purpose is to provide you with an approximate measurement in relation to your target heart rate. Use of a chest transmitter strap (sold separately) is a much more accurate method of heart rate analysis. Various factors, including the user's movement, may affect the accuracy of heart rate readings. The pulse sensors are intended only as exercise aids in determining heart rate trends in general.
12. Wear proper shoes. High heels, dress shoes, sandals or bare feet are not suitable for use on your elliptical. Quality athletic shoes are recommended to avoid leg fatigue.
13. This exercise equipment is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the exercise equipment by a person responsible for their safety.
14. Before beginning this or any exercise program, consult a physician. This is especially important for persons over the age of 35 or persons with pre-existing health conditions.
15. Close supervision is necessary when this exercise equipment is used by, on, or near children, invalids, or disabled persons.

**SAVE THESE INSTRUCTIONS - THINK SAFETY!**

# Fitness Equipment Safety Instructions

To disconnect turn all controls to the off position, then remove the plug from the outlet.

- Do not operate equipment on deeply padded, plush or shag carpet. Damage to both carpet and equipment may result.
- Before beginning this or any exercise program, consult a physician. This is especially important for persons over the age of 35 or persons with pre-existing health conditions.
- Do not attempt to use your equipment for any purpose other than for the purpose it is intended.
- Keep hands away from all moving parts.
- The pulse sensors are not medical devices. Their purpose is to provide you with an approximate measurement in relation to your target heart rate. Use of a chest transmitter strap (sold separately) is a much more accurate method of heart rate analysis. Various factors, including the user's movement, may affect the accuracy of heart rate readings. The pulse sensors are intended only as exercise aids in determining heart rate trends in general.
- Wear proper shoes. High heels, dress shoes, sandals or bare feet are not suitable for use on your equipment. Quality athletic shoes are recommended to avoid leg fatigue.  
Failure to follow all guidelines may compromise the effectiveness of the exercise experience, expose yourself (and possibly others) to injury, and reduce the longevity of the equipment.

## Important Electrical Instructions

### ***WARNING!***

**NEVER** remove any cover without first disconnecting DC power. If voltage varies by ten percent (10%) or more, the performance of your elliptical may be affected. Such conditions are not covered under your warranty. If you suspect the voltage is low, contact your local power company or a licensed electrician for proper testing.

**NEVER** expose this elliptical to rain or moisture. This product is **NOT** designed for use outdoors, near a pool or spa, or in any other high humidity environment. The operating temperature specification is 5 to 48 degrees Celsius (40 to 120 degrees Fahrenheit), and humidity is 95 non-condensing (no water drops forming on surfaces).

# Important Operation Instructions


- **NEVER** operate this elliptical without reading and completely understanding the results of any operational change you request from the computer.
- Understand that changes in resistance do not occur immediately. Set your desired resistance level on the computer console and release the adjustment key. The computer will obey the command gradually.
- **NEVER** use your elliptical during an electrical storm. Surges may occur in your household power supply that could damage elliptical components. Unplug the elliptical during an electrical storm as a precaution.
- Use caution while participating in other activities while pedaling on your elliptical; such as watching television, reading, etc. These distractions may cause you to lose balance which may result in serious injury.
- Do not use excessive pressure on console control keys. They are precision set to function properly with little finger pressure.

## Grounding Instructions

**This product must be grounded.** If the your equipment should malfunction or breakdown, grounding provides a path of least resistance for electric current, reducing the risk of electric shock. This product is equipped with a cord having an equipment-grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

**DANGER** - Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the product is properly grounded. Do not modify the plug provided with the product if it will not fit the outlet; have a proper outlet installed by a qualified electrician.

This product is for use on a nominal 110-volt/15 amp (220-volt/10 amp) dedicated circuit, and has a grounding plug that looks like the plug illustrated below. A temporary adapter that looks like the adapter illustrated below may be used to connect this plug to a 2-pole receptacle as shown below if a properly grounded outlet is not available. The temporary adapter should be used only until a properly grounded outlet, (shown below) can be installed by a qualified electrician. The green colored rigid ear-lug, or the like, extending from the adapter, must be connected to a permanent ground such as a properly grounded outlet box cover. Whenever the adapter is used, it must be held in place by a metal screw.




# Assembly Instructions


## PRE-ASSEMBLY

1. Using a razor knife (Box Cutter), cut the banding straps that wrap around the carton. Reach under the bottom edge of the carton and pull it away from the cardboard underneath, separating the staples that join the two together. Lift the box over the unit and unpack.
2. Carefully remove all parts from carton and inspect for any damage or missing parts. If damaged parts are found, or parts are missing, contact your dealer immediately.
3. Locate the hardware package. The hardware is separated into four steps. Remove the tools first. Remove the hardware for each step as needed to avoid confusion. The numbers in the instructions that are in parenthesis (**#**) are the item number from the assembly drawing for reference.


## ASSEMBLY TOOLS




**#157.** Phillips Head Screw Driver (1 pc)



**#177.** Combination M5 Allen Wrench & Phillips Head Screw Driver (1 pc)



**#155.** 13/14mm Wrench (1 pc)




**#158.** 12/14mm Wrench (1 pc)

# STEP 1: Rail Assembly & Console Mast

1. Locate the **CONSOLE MAST (12)** and **CONSOLE MAST COVER (72)**; slide the Cover onto the Mast as far as it will go. Make sure the **CONSOLE MAST COVER (72)** is facing the correct way.
2. At the top opening of the **MAIN FRAME (1)**, there is a **COMPUTER CABLE (50)** tied to a twist tie wire. Feed the twist tie wire and **COMPUTER CABLE (50)** into the bottom of the **CONSOLE MAST (12)** and out of the opening at the top.
3. Install the **CONSOLE MAST (12)** into the receiving bracket on the top of the **MAIN FRAME (1)**. Be extremely careful not to pinch the cables between the tubing. If the cable gets pinched, this may affect the electrical functions of the console.  
*NOTE: There is one bolt already installed in the receiving bracket that will engage with the slot at the bottom of the Console Mast. This needs to be tightened last, after the three other console mast bolts.*
4. Place a **SPLIT WASHER (152)** onto the **BOLT (105)** and hand tighten through the left side of the console mast. Place a **CURVED WASHER (153)** onto each **BOLT (103)** and thread both into the front of the console mast tube. Fasten these front bolts as tight as possible with the **WRENCH (155)**. Next firmly tighten the two left side bolts with the same wrench.
5. Connect the 2 **HAND PULSE CABLES (48)**, **RESISTANCE CABLE (44)**, and **COMPUTER CABLE (50)** to the back of the **CONSOLE (43)**. Do not force the connectors; they will only fit one way and are different sizes to prevent confusion. Store the excessive cable in the **CONSOLE MAST TUBE (12)**.
6. Attach the **CONSOLE (43)** to the bracket of the Console Mast tube with 4 **PHILLIPS HEAD SCREWS (116)**. Tighten the screws with the **PHILLIPS HEAD SCREW DRIVER (157)**.
7. Attach the **REAR FLOOR SUPPORT (15)** to the **RAILS (2 & 3)** with 2 **BUTTON HEAD SOCKET BOLTS (176)** and **CURVED WASHERS (153)** on each side. Tighten using the **COMBINATION M5 ALLEN WRENCH & PHILLIPS HEAD SCREW DRIVER (177)**.
8. Slide the Rail Assembly into the **MAIN FRAME (1)**. Insert one **BUTTON HEAD SOCKET BOLT (176)** through each side and attach a **FLAT WASHER (137)** and a **NYLOC NUT (130)** to each joint on the inside.


## HARDWARE




**#137.** 3/8" x 19 x 1.5T  
Flat Washer (2 pcs)



**#116.** M5 x 10m/m  
Phillips Head Screw  
(4 pcs)



**#153.** 3/8" x 23 x 2T  
Curved Washer (6 pcs)




**#176.** 3/8" x 2-1/4"  
Button Head Socket Bolt  
(6 pcs)




**#152.** 3/8" x 2T  
Spilt Washer (1 pc)




**#130.** 3/8" x 7T  
Nyloc Nut (2 pcs)




**#120.** 3.5 x 16m/m  
Sheet Metal Screw (3 pcs)




**#103.** 3/8" x 3/4"  
Hex Head Bolt (2 pcs)



**#105.** 3/8" x 2-1/4"  
Hex Head Bolt (1 pc)






## STEP 2: Connecting & Lower Swing Arms

1. Slide 2 **WAVE WASHERS (150)** onto both the Left and Right Console Mast axle. Slide the **SWING ARMS (L) and (R), (10 & 11)** onto the appropriate side of the axle. *NOTE: Make sure the arms are attached as shown in the illustration.*
2. Place a **FLAT WASHER (141)** onto each **BOLT (99)** and fasten in the end of the left and right axle. Tighten with the **WRENCH (155)**.


### HARDWARE




#150. Ø 17 m/m  
Wavy Washer (4 pcs)



#141. 5/16" x 23 x 1.5T  
Flat Washer (2 pcs)



#99. 5/16" x 15mm  
Hex Head Bolt (2 pcs)




## STEP 3: Connecting Arm

1. Untie the twist tie that holds each bushing to the Connecting Arm end. Align the hole in the end of the **CONNECTING ARMS (L & R) (8 & 9)** with the hole in the bracket of the **SWING ARMS (L) AND (R), (10 & 11)**. The **CONNECTING ARM** ends should be inside of the **SWING ARM (L) AND (R), (10 & 11)** brackets. Slide a **HEX HEAD BOLT (101)** through each **SWING ARM (L) AND (R), (10 & 11)** bracket and each Connecting Arm end.
2. Slide a **FLAT WASHER (142)** onto each bolt, then fasten the arms together by tightening a **NYLOC NUT (192)** to each bolt using the **WRENCHES** provided (**155 & 158**).


### HARDWARE




**#192.** 5/16" x 9T  
Nyloc Nut (2 pcs)



**#101.** 5/16" x 1-1/4"  
Hex Head Bolt (2 pcs)



**#142.** 5/16" x 20 x 1.5T  
Flat Washer (2 pcs)




## STEP 4: Plastic Parts

1. Fasten the two **WHEEL COVERS (79)** to the rollers with 4 **PHILLIPS HEAD SCREWS (115)**. Tighten with the **PHILLIPS HEAD SCREW DRIVER (157)**.
2. Attach the **LEFT AND RIGHT SIDE COVER (80)** to the mid-stabilizer tube with 2 **PHILLIPS HEAD SCREWS (115)**. Attach the **RIGHT SIDE COVER (85)** and **LEFT SIDE COVER (86)** to the rear stabilizer tube with 2 **PHILLIPS HEAD SCREWS (115)**. Tighten all 4 screws with the **PHILLIPS HEAD SCREW DRIVER (177)**.
3. Install the **LEFT HANDLE BAR COVERS (81 & 82)** and **RIGHT HANDLE BAR COVERS (83 & 84)** over the Handle Bar axle connections with 3 **SHEET METAL SCREWS (119)** on each side. Tighten with the **PHILLIPS HEAD SCREW DRIVER (157)**.
4. Look closely at the four floor levelers underneath the middle and rear of the elliptical. If any of these aren't in contact with the floor, use the **WRENCH (155)** to loosen the bottom nut. Once the nut has been loosened, turn the rubber caster clockwise until it makes solid contact with the floor. Retighten the bottom nut to prevent it from moving.

### HARDWARE




**#119.** Ø 3.5 × 12mm  
Sheet Metal Screw (6 pcs)



**#115.** M5 × 12mm  
Phillips Head Screw (8 pcs)

# Operation Of Your Console

## GETTING FAMILIAR WITH THE CONTROL PANEL



## POWER

When the power cord is connected to the elliptical, the console will automatically power up.

When initially powered on the console will perform an internal self-test. During this time all the lights will turn on. When the lights go off, the Message Center will show the software version (i.e.: VER 1.0). The distance window shows the distance total and the time window shows the total hours of use.

The odometer will remain displayed for only a few seconds then the console will go to the start up display. The dot matrix display will be scrolling through the different profiles of the programs and the Message Center will be scrolling the start up message. You may now begin to use the console.

## Quick Start

This is the quickest way to start a workout. After the console powers up you just press the **Start** key to begin, this will initiate the Quick Start mode. In Quick Start the Time will count up from zero and the workload may be adjusted manually by pressing the **Level Up/Down** keys. The dot matrix display will have only the bottom row lit at first. As you increase the work load more rows will light indicating a harder workout. The elliptical trainer will get harder to pedal as the rows increase.

There are 20 levels of resistance available for plenty of variety. The first 5 levels are very easy workloads and the changes between levels are set to a good progression for de-conditioned users. Levels 6-10 are more challenging, but the increases in resistance from one level to the next remain small. Levels 11-15 start getting tough as the levels jump more dramatically. Levels 16-20 are extremely hard and are good for short interval peaks and elite athletic training.

## Basic Information

The Message Center will initially be displaying the Program name. When in scan mode during a program, speed will be displayed for four seconds, then move on and display Watts (indication of workload). If 100 watts is displayed, you are doing enough work to keep a 100-watt light bulb lit. The data changes to Laps completed, Segment time, Max level. Pressing the **Enter** key again will bring you back to the beginning.

The **Stop** key actually has several functions. Pressing the **Stop** key once during a program will pause the program for 5 minutes. If you need to get a drink, answer the phone or any of the many things that could interrupt your workout, this is a great feature. To resume your workout during Pause, just press the **Start** key. If the **Stop** key is pressed twice during a workout, the program will end and the console will display your Workout Summary (Total time, Avg. Speed, Avg. Watts, Avg. HR, total Laps). If the **Stop** key is held down for 3 seconds or a third time during the program, the console will perform a complete **Reset**. During data entry for a program the **Stop** key performs a previous screen or segment function. This allows you to go back to change programming data.

## Program Keys

The program keys are used to preview each program. When you first turn the console on you may press each program key to preview what the program profile looks like. If you decide that you want to try a program, press the corresponding program key and then press the **Enter** key to select the program and enter into the data-setting mode.

The elliptical trainer has a built in heart rate monitoring system. Simply grasping the hand pulse sensors on the stationary handle bars or wearing the heart rate transmitter (see Using Heart Rate Transmitter section) will start the Heart Icon blinking (this may take a few seconds). The Pulse Display Window will display your heart rate, or Pulse in beats per minute.

The console includes a built-in fan to help keep you cool. To turn the fan on, press the key on the left side of the console.

## Programming The Console

Each of the programs can be customized with your personal information and changed to suit your needs. Some of the information asked for is necessary to ensure the readouts are correct. You will be asked for your Age and Weight. Entering your Age is necessary during the Heart Rate programs to ensure the correct settings are in the program for your Age. Otherwise the work settings could be too high or low for you. Entering your Weight aides in calculating a more correct Calorie reading. Although we cannot provide an exact calorie count, we do want to be as close as possible.

*CALORIE NOTE:* Calorie readings on every piece of exercise equipment, whether it is in a gym or at home, are not accurate and tend to vary widely. They are meant only as a guide to monitor your progress from workout to workout. The only way to measure your calorie burn accurately is in a clinical setting connected to a host of machines. This is because every person is different and burns calories at a different rate. Some good news is that you will continue to burn calories at an accelerated rate for at least an hour after you have finished exercising!

## Entering A Program And Changing Settings

When you enter a program, by pressing a program key, then **Enter** key, you have the option of entering your own personal settings. If you want to workout without entering new settings, then just press the **Start** key. This will bypass the programming of data and take you directly to the start of your workout. If you want to change the personal settings then just follow the instructions in the Message Center. If you start a program without changing the settings, the default or saved settings will be used.

**NOTE:** Age and Weight default settings will change when you enter a new number. So the last Age and Weight entered will be saved as the new default settings. If you enter your Age and Weight the first time you use the elliptical, you will not have to enter it every time you work out unless either your Age or Weight changes or someone else enters a different Age and Weight.

# Programmable Features

## Manual

The Manual program works as the name implies, manually. This means that you control the workload and not the computer. To start the Manual program, follow the instructions below or just press the **Start** key.


1. Press the **Manual** key, then press the **Enter** key.
2. The Message Center will ask you to enter your Age. You may enter your age, using the **Level Up/Down** keys, then press the **Enter** key to accept the new value and proceed on to the next screen.
3. You are now asked to enter your Weight. You may adjust the Weight value using the **Level Up/Down** keys, then press **Enter** to continue.
4. Next is Time. You may adjust the Time and press **Enter** to continue.
5. Now you are finished editing the settings and can begin your workout by pressing the **Start** key. You can also go back and modify your settings by pressing the **Enter** key.
6. Once the program starts you will be at level one. This is the easiest level and it is a good idea to stay at level one for a while to warm up. If you want to increase the work load at any time press the **Level Up** key; the **Level Down** key will decrease the work-load.
7. During the Manual program you will be able to scroll through the data in the Message Center by pressing the **Enter** key.
8. When the program ends you may press **Start** to begin the same program again or **Stop** to exit the program.

# Preset Programs

The elliptical has four different programs that have been designed for a variety of workouts. These four programs have factory preset work level profiles for achieving different goals.


## HILL

This program follows a triangle or pyramid type of gradual progression from approximately 10% of maximum effort (the level that you chose before starting this program) up to a maximum effort which lasts for 10% of the total workout time, then a gradual regression of resistance back to approximately 10% of maximum effort.




## FAT BURN

This program follows a quick progression up to the maximum resistance level (default or user input level) that is sustained for 2/3 of the workout. This program will challenge your ability to sustain your energy output for an extended period of time.



## CARDIO


This program presents a quick progression up to near maximum resistance level (default or user input level). It has slight fluctuations up and down to allow your heart rate to elevate, and then recover repeatedly, before beginning a quick cool down. This will build up your heart muscle and increase blood flow and lung capacity.



## INTERVAL

This program takes you through high levels of intensity followed by recovery periods of low intensity.

This program utilizes and develops your "Fast Twitch" muscle fibers which are used when performing tasks that are intense and short in duration. These deplete your oxygen level and spike your heart rate, followed by periods of recovery and heart rate drop to replenish oxygen. Your cardiovascular system gets programmed to use oxygen more efficiently.



# Programming Preset Programs

1. Select the desired program key then press the **Enter** key.
2. The Message Center will ask you to enter your Age. You may adjust the age setting, using the **Level Up/Down** keys, then press the **Enter** key to accept the new number and proceed on to the next screen.
3. You are now asked to enter your Weight. You may adjust the Weight value using the **Level Up/Down** keys, then press **Enter** to continue.
4. Next is Time. You may adjust the time and press **Enter** to continue.
5. Now you are asked to adjust the Max Resistance Level. This is the peak exertion level you will experience during the program. Adjust the level and then press **Enter**.
6. Now you are finished editing the settings and can begin your workout by pressing the **Start** key. You can also go back and modify your settings by pressing the **Enter** key.
7. If you want to increase or decrease the resistance at any time during the program, press the **Level Up/Down** keys on the console or above the heart rate sensor grips of the stationary handlebars. This will change the resistance settings of the entire profile, although the profile picture on the screen will not change. The reason for this is so that you can see the entire profile at all times. If the profile picture is changed, it also would be distorted and not a true representation of the actual profile. When you make a change to the resistance, the Message Center will show the current column and program maximum levels of work.
8. During the program you will be able to scroll through the data in the message window by pressing the **Enter** key.
9. When the program ends the Message Center will show a summary of your workout. The summary will be displayed for a short time, then the console will return to the start-up display

# Heart Rate Programs

Before we get started, a word about Heart Rate:

The old motto, “no pain, no gain”, is a myth that has been overpowered by the benefits of exercising comfortably. A great deal of this success has been promoted by the use of heart rate monitors. With the proper use of a heart rate monitor, many people find that their usual choice of exercise intensity was either too high or too low and exercise is much more enjoyable by maintaining their heart rate in the desired benefit range.


To determine the benefit range in which you wish to train, you must first determine your Maximum Heart Rate. This can be accomplished by using the following formula: 220 minus your age. This will give you the Maximum heart rate (MHR) for someone of your age. To determine the effective heart rate range for specific goals you simply calculate a percentage your MHR. Your Heart rate training zone is 50% to 90% of your maximum heart rate. 60% of your MHR is the zone that burns fat while 80% is for strengthening the cardio vascular system. This 60% to 80% is the zone to stay in for maximum benefit.

For someone who is 40 years old their target heart rate zone is calculated:

$220 - 40 = 180$  (maximum heart rate)  
 $180 \times .6 = 108$  beats per minute (60% of maximum)  
 $180 \times .8 = 144$  beats per minute (80% of maximum)

So for a 40 year old the training zone would be 108 to 144 beats per minute.

If you enter your age during programming the console will perform this calculation automatically. Entering your age is used for the Heart Rate control programs. After calculating your Maximum Heart Rate you can decide upon which goal you would like to pursue.



The two most popular reasons for, or goals, of exercise are cardiovascular fitness (training for the heart and lungs) and weight control. The black columns on the chart above represent the Maximum Heart Rate for a person whose age is listed at the bottom of each column. The training heart rate, for either cardiovascular fitness or weight loss, is represented by two different lines that cut diagonally through the chart. A definition of the lines' goal is in the bottom left-hand corner of the chart. If your goal is cardiovascular fitness or if it is weight loss, it can be achieved by training at 80% or 60%, respectively, of your Maximum Heart Rate on a schedule approved by your physician. Consult your physician before participating in any exercise program.

With all Heart Rate Control elliptical machines you may use the heart rate monitor feature without using the Heart Rate Control program. This function can be used during manual mode or during any of the nine different programs. The Heart Rate Control program automatically controls resistance at the pedals.

# Rate Of Perceived Exertion

Heart rate is important but listening to your body also has a lot of advantages. There are more variables involved in how hard you should workout than just heart rate. Your stress level, physical health, emotional health, temperature, humidity, the time of day, the last time you ate and what you ate, all contribute to the intensity at which you should workout. If you listen to your body, it will tell you all of these things. The rate of perceived exertion (RPE), also know as the Borg scale, was developed by Swedish physiologist G.A.V. Borg. This scale rates exercise intensity from 6 to 20 depending upon how you feel or the perception of your effort.

The scale is as follows:

## Rating Perception of Effort

- 6 Minimal
- 7 Very, very light
- 8 Very, very light +
- 9 Very light
- 10 Very light +
- 11 Fairly light
- 12 Comfortable
- 13 Somewhat hard
- 14 Somewhat hard +
- 15 Hard
- 16 Hard +
- 17 Very hard
- 18 Very hard +
- 19 Very, very hard
- 20 Maximal

You can get an approximate heart rate level for each rating by simply adding a zero to each rating. For example a rating of 12 will result in an approximate heart rate of 120 beats per minute. Your RPE will vary depending up the factors discussed earlier. That is the major benefit of this type of training. If your body is strong and rested, you will feel strong and your pace will feel easier. When your body is in this condition, you are able to train harder and the RPE will support this. If you are feeling tired and sluggish, it is because your body needs a break. In this condition, your pace will feel harder. Again, this will show up in your RPE and you will train at the proper level for that day.

## Using A Heart Rate Transmitter (OPTIONAL)

How to wear your wireless chest strap transmitter:

1. Attach the transmitter to the elastic strap using the locking parts.
2. Adjust the strap as tightly as possible as long as the strap is not too tight to remain comfortable.
3. Position the transmitter with the logo centered in the middle of your body facing away from your chest (some people must position the transmitter slightly left of center). Attach the final end of the elastic strap by inserting the round end and, using the locking parts, secure the transmitter and strap around your chest.
4. Position the transmitter immediately below the pectoral muscles.
5. Sweat is the best conductor to measure very minute heart beat electrical signals. However, plain water can also be used to pre-wet the electrodes (2 ribbed oval areas on the reverse side of the belt and both sides of the transmitter). It's also recommended that you wear the transmitter strap a few minutes before your work out. Some users, because of body chemistry, have a more difficult time in achieving a strong, steady signal at the beginning. After "warming up", this problem lessens. As noted, wearing clothing over the transmitter/strap doesn't affect performance.
6. Your workout must be within range - distance between transmitter/receiver – to achieve a strong steady signal. The length of range may vary somewhat but generally stay close enough to the console to maintain good, strong, reliable readings. Wearing the transmitter immediately against bare skin assures you of proper operation. If you wish, you may wear the transmitter over a shirt. To do so, moisten the areas of the shirt that the electrodes will rest upon.



*Note: The transmitter is automatically activated when it detects activity from the user's heart.*

*Additionally, it automatically deactivates when it does not receive any activity. Although the transmitter is water resistant, moisture can have the effect of creating false signals, so you should take precautions to completely dry the transmitter after use to prolong battery life (estimated transmitter battery life is 2500 hours). The replacement battery is Panasonic CR2032.*

## Erratic Operation

**Caution!** Do not use this elliptical for Heart Rate Control unless a steady, solid Actual Heart Rate value is being displayed. High, wild, random numbers being displayed indicate a problem.

Areas to look for interference which may cause erratic heart rate:

1. Microwave ovens, TV's, small appliances, etc.
2. Fluorescent lights.
3. Some household security systems.
4. Perimeter fence for a pet.
5. Some people have problems with the transmitter picking up a signal from their skin. If you have problems try wearing the transmitter upside down. Normally the transmitter will be oriented so the logo is right side up.
6. The antenna that picks up your heart rate is very sensitive. If there is an outside noise source, turning the whole machine 90 degrees may de-tune the interference.
7. Another Individual wearing a transmitter within 3' of your machine's console.

If you continue to experience problems contact your dealer.

# Using the Spirit FIT App

In order to help you achieve your exercise goals, your new exercise machine comes equipped with a Bluetooth® transceiver that will allow it to interact with selected phones or tablet computers via the Spirit Fit App.

Just download the free Spirit Fit App from the Apple Store or Google Play, and then follow the instructions in the App to sync with your exercise machine. Now you can view current workout data in three different Display screens on your device. You can also easily switch back and forth from the workout display view to internet/social media/email sites via icons on the display screen. When your workout is finished, the data is automatically saved to the built-in personal calendar for future reference.

The Spirit Fit App also allows you to sync your workout data with one of many fitness cloud sites we support: iHealth, MapMyFitness, Record or Fitbit, with more to come. Syncing the App with your exercise machine:



1. Download the App.
2. Open the App on your device (phone or tablet) and make sure Bluetooth® is enabled on your device(phone or tablet).
3. In the App click the icon in the top left corner to search for your Spirit equipment (shown right).
4. After the equipment is detected, click Connect. When the App and equipment are synced, the Bluetooth® icon on the equipment's console display will light up. You may now start using your new Spirit Fitness product.
5. When your workout is finished, the data is automatically saved and you will be prompted to sync your data with each available fitness cloud site. Please note you will have to download the applicable compatible fitness App, such as iHealth, MapMyFitness, Record, Fitbit, etc, in order for the icon to be active and available.

Note: Your device will need to be running on a minimum operating system of iOS 7 or Android 4.4 for the Spirit Fit App to operate properly.

# Heart Rate Program Operation

*Note: You must wear the heart rate transmitter strap for these programs.*

The Heart Rate program default setting is 60% of your projected maximum heart rate. The 60-80% range is more conducive for fat loss goals and 81-100% ranges are generally used for cardiovascular conditioning goals and high intensity interval training.

To start an HR program follow the instructions below or just select the **HR** key, then the **Enter** key and follow the directions in the Message Center.

After selecting your heart rate target the program will attempt to keep you at or within 3-5 heart beats per minute of this value. Follow the prompts in the Message Center to maintain your selected heart rate value.

1. Press the **HR** key then press the **Enter** key.
2. The Message Center will ask you to enter your Age. You may enter your age, using the **Level Up/Down keys**, then press the **Enter** key to accept the new value and proceed on to the next screen.
3. You are now asked to enter your Weight. You may adjust the weight value using the **Level Up/Down keys**, then press **Enter** to continue.
4. Next is Time. You may adjust the time and press **Enter** to continue.
5. Now you are asked to adjust the Heart Rate Target. This is the heart rate level you will strive to maintain during the program. Adjust the level using the **Level Up/Down keys**, then press **Enter**. *Note: The heart rate that appears is based on the % you accepted in [Step 1](#). If you change this number it will either increase or decrease the % from [Step 1](#).*
6. Now you are finished editing the settings and can begin your workout by pressing the **Start** key. You can also go back and modify your settings by pressing the **Enter** key.
7. If you want to increase or decrease the workload at any time during the program press the **Level Up/Down key**. This will allow you to change your target heart rate at any time during the program.
8. During the HR program you will be able to scroll through the data in the Message Center by pressing the **Enter** key.
9. When the program ends you may press **Start** to begin the same program again or **Stop** to exit the program.

# General Maintenance


1. Wipe down all areas in the sweat path with a damp cloth after each workout.
2. If a squeak, thump, clicking or rough feeling develops the main cause is most likely one of several reasons:
  - i. The hardware was not sufficiently tightened during assembly. All bolts that were installed during assembly need to be tightened as much as possible. It may be necessary to use a larger wrench than the one provided if you cannot tighten the bolts sufficiently. I cannot stress this point enough; 90% of calls to the service department for noise issues can be traced to loose hardware.
  - ii. Dirt build-up on the rear rails and polyurethane wheels are also a source of noise. Noise from build-up on the rails can cause a thumping sound that you would swear is coming from inside the main body of the machine because noise travels, and is amplified, in the tubing of the frame. Clean the rails and wheels with a lint free cloth and rubbing alcohol. Stubborn build-up can be removed with your thumbnail or a nonmetallic scraper, like the back edge of a plastic knife. After cleaning, apply a small amount of lubricant on the rails with your fingers or a lint free cloth. You only need a thin coat of lubrication, wipe off any excess.
  - iii. The crank arm nut needs to be retightened
  - iv. If squeaks or other noises persist, check that the unit is properly leveled. There are 2 leveling pads on the bottom of the rear stabilizer, use a 14mm wrench (or adjustable wrench) to adjust the levelers.

# Engineering Mode Menu

The console has built in maintenance/diagnostic software. The software will allow you to change the console settings from English to Metric and turn off the beeping of the speaker when a key is pressed for example. To enter the Engineering Mode Menu, press and hold down the **Start**, **Stop** and **Enter** keys. Keep holding the keys down for about 5 seconds and the message center will display Engineering Mode Menu. Press the **Enter** button to access the menu below:

1. KeyTest (Will allow you to test all the keys to make sure they are functioning)
2. LCDTest (Tests all the display functions)
3. Functions (Press **Enter** to access settings and **Up** arrow to scroll)
  - i. Display Mode (Turn off to have the console power down automatically after 20 minutes of inactivity)
  - ii. Pause Mode (Turn on allow 5 minutes of pause, turn off to have the console pause indefinitely)
  - iii. ODO Reset (Resets the odometer)
  - iv. Units (Sets the display to readout in English or Metric display measurements)
  - v. Beep (Turns off the speaker so no beeping sound is heard)
  - vi. Motor Test
  - vii. Safety
4. Security (Allows the keypad to be locked to prevent unauthorized use)

# Exploded View Diagram



# Parts List

NO.	DESCRIPTION	Q'TY
1	Main Frame	1
2	Rear Rail Assembly	2
3	Console Holder Assembly	1
4	Cross Bar	2
5	Bushing Housing, Pedal Arm	2
6	Pedal Arm (L)	1
7	Pedal Arm (R)	1
8	Connecting Arm (L)	1
9	Connecting Arm (R)	1
10	Swing Arm (L)	1
11	Swing Arm (R)	1
12	Console Mast	1
13	Idler Wheel Assembly	1
14	Crank Axle	1
15	Rear Rail Assembly	1
20	Rod End Sleeve	4
21	Axle Stopper	1
23	Axle for Pedal	2
25	Axle for Slide Wheel	2
27	Aluminum Track	2
28	6005_Bearing	2
29	6003_Bearing	12
30	6203_Bearing	2
31	Rod End Bearing	2
32	Drive Belt	1
33	Flywheel	1
34	Magnet	1
35	Handgrip Foam	2
36	Steel Cable	1
39	Drink Bottle Holder	1
40	Resistance Button W/Cable	2
41	Handgrip Resistance Label (UP)	1
42	Handgrip Resistance Label (DOWN)	1
43	Console Assembly	1
43~1	Console Top Cover	1
43~2	Console Bottom Cover	1
43~3	Deflector Fan Grill	1
43~4	Wind Duct (L)	1
43~5	Wind Duct (R)	1
43~7	Fan Grill Anchor	2

<b>NO.</b>	<b>DESCRIPTION</b>	<b>Q'TY</b>
43~8	LCD Transparent Piece	1
43~9	Water-resist Rubber	1
43~10	Book Rack	1
43~11	Console Bottom Cover	1
43~12	Fan Fixing Plate	2
43~13	Console Display Board	1
43~14	Interface Board	1
43~15	Key Board	1
43~16	400m/m_Fan Assembly(White)	1
43~17	300m/m_W/Receiver, HR	1
43~18	Bluetooth	1
44	1200m/m_Computer Cable	1
45	600m/m_DC Power Cord	1
46	Gear Motor	1
47	400m/m_Sensor W/Cable	1
48	850m/m_Handpulse W/Cable Assembly	2
49	Power Adaptor	1
50	900m/m_Resistance Connecting Cable	1
58	Transportation Wheel	2
59	Slide Wheel , Urethane	2
60	Rubber Foot	4
61	WFM-2528-21_Bushing	4
63	Button Head Plug	2
64	Ø32 × 1.8T_Round Cap	4
65	32 × 2.5T_Round Cap	2
66	Ø25.5 × 33.5 × 1.5T_Nylon Wave Washer	2
69	Ø30 × 19m/m_Mast Bushing	2
70	Pedal (L)	1
71	Pedal (R)	1
72	Console Mast Cover (L)	1
72~1	Console Mast Cover (R)	1
73	Side Case(L)	1
74	Side Case(R)	1
75	Round Disk	2
76	Round Disk Cover	2
77	Pedal Arm Cover (L)	1
78	Pedal Arm Cover (R)	1
79	Slide Wheel Cover	2
80	Middle Stabilizer Cover	2
81	Front Handle Bar Cover (L)	1

<b>NO.</b>	<b>DESCRIPTION</b>	<b>Q'TY</b>
82	Rear Handle Bar Cover (L)	1
83	Front Handle Bar Cover (R)	1
84	Rear Handle Bar Cover (R)	1
85	Rear Stabilizer Cover (L)	1
86	Rear Stabilizer Cover (R)	1
89	Spacer Bushing	1
90	Drive Pulley	1
93	Oval End Cap (Bevel)	4
94	Sensor Rack	1
96	Handgrip End Cap	2
97	7 x 7 x 19L_Woodruff Key	2
98	1/4" x 3/4" _Hex Head Bolt	4
99	5/16" x UNC18 x 15m/m _Hex Head Bolt	12
100	5/16" x UNC18 x 15m/m _Flat Head Socket Bolt	2
101	5/16" x 1-1/4" _Hex Head Bolt	2
103	3/8" x 3/4" _Hex Head Bolt	2
105	3/8" x 2-1/4" _Hex Head Bolt	2
108	3/8" x 2-1/4" _Socket Head Cap Bolt	2
110	M8 x 40m/m _Socket Head Cap Bolt	2
111	3/8" x 1-3/4" _Flat Head Socket Bolt	4
112	5/16" x 1-3/4" _Button Head Socket Bolt	2
115	M5 x 12m/m _Phillips Head Screw	14
116	M5 x 10m/m _Phillips Head Screw	6
117	M5 x 10m/m _Phillips Head Screw	10
118	5 x 19m/m _Tapping Screw	11
119	3.5 x 12m/m _Sheet Metal Screw	6
120	3.5 x 16m/m _Sheet Metal Screw	13
121	5 x 16m/m _Tapping Screw	16
123	3 x 20m/m _Tapping Screw	4
124	Ø25 _C Ring	2
125	Ø17 _C Ring	1
126	1/4" x 8T _Nyloc Nut	4
127	5/16" x 7T _Nyloc Nut	3
128	M8 x 7T _Nyloc Nut	1
129	M8 x 9T _Nyloc Nut	1
130	3/8" x 7T _Nyloc Nut	2
131	3/8" x 11T _Nyloc Nut	2
132	3/8" x UNF26 x 4T _Nut	2
133	3/8" x UNF26 x 11T _Nut	2
134	3/8" x 7T _Nut	8
135	M8 x 6.3T _Nut	4
136	Ø17x 23.5 x 1T _Flat Washer	1

<b>NO.</b>	<b>DESCRIPTION</b>	<b>Q'TY</b>
137	Ø3/8" x Ø19 x 1.5T_Flat Washer	10
139	Ø5/16" x Ø35 x 1.5T_Flat Washer	5
141	Ø5/16" x Ø23 x 1.5T_Flat Washer	10
142	Ø5/16" x Ø20 x 1.5T_Flat Washer	2
144	Ø1/4" x 19m/m_Flat Washer	17
145	M8 x 170m/m_J Bolt	1
146	M8 x 20m/m_Carriage Bolt	1
147	M5 x P0.8 x 6m/m_Socket Head Cap Bolt	2
149	Ø25_Wave Washer	2
150	Ø17_Wave Washer	6
152	Ø10 x 2T_Split Washer	2
153	Ø3/8" x 23 x 2T_Curved Washer	6
155	13/14m/m_Wrench	1
157	Phillips Head Screw Driver	1
158	12/14m/m_Wrench	1
171	5/16" x 25 x 3T_Nylon Washer	2
172	5/16" x 2-1/2" _Hex Head Bolt	1
176	3/8" x 2-1/4" _Button Head Socket Bolt	6
177	Combination M5 Allen Wrench & Phillips Head Screw Driver	1
178	13m/m_Bolt Cap	1
180	Rubber Foot Pad	2
192	5/16" x 9T_Nyloc Nut	2
193	Ø15 x Ø8.5 x 50L_Sleeve	2
194	E-Clip	2
195	Transformer Power Cord	1
196	Ø5/16" x Ø23 x 3.0T_Flat Washer	4
199	Rubber Pad(Ø25.5xØ30x1T)	1